

# SaltTestr

Conductivity Measurement Testers



## Non-linear curve programmed for best results in testing NaCl in water applications

### Factory calibrated against NaCl standards

ideal for testing salinity levels in pools

### Non-linear curve programmed for best results in testing NaCl in water applications

### 1% full-scale accuracy

The best in its class!

### Waterproof, dustproof housing

Meets IP67 ratings, plus—it floats!

### Replaceable electrode

Reuse same meter body over and over again

### Push-button calibration

calibrate more precisely than trimpot adjustment; no screwdrivers necessary

### Hold function

freezes reading until you can log it

### Auto shut-off

saves your batteries

### Full reading displayed

no need to multiply the readout to obtain actual test values

### Automatic temperature compensation (ATC)

gives you accurate measurements even in fluctuating temperatures

### Applications

For aquariums, hobbyists (koi fish), aquaculture, fish farms, water and wastewater treatment, pools, and spas.

**New**



SaltTestr  
35661-51



Convenient soft vinyl belt-loop carrying case keeps tester handy



Calibration button tucked away in battery compartment to avoid accidental recalibration



Replaceable electrodes extend tester life and save you money



### Specifications

Model	Waterproof SaltTestr
Range	0 to 10.00 ppt
Resolution	0.10 ppt
Accuracy	0.00 to 7.00 ppt: $\pm 1\%$ FS; above 7.00 ppt: $\pm 3\%$ FS
Calibration	One point push-button calibration (using keys inside battery compartment)
Calibration standard range	3 to 10.00 ppt*
Operating temp	0 to 50°C (32 to 122°F)
Temperature compensation	Automatic (ATC) from 0 to 50°C (32 to 122°F)
ATC coefficient	2% per °C, 25°C reference temperature
Power and battery life	Four 1.5 V alkaline batteries Eveready A76 (included), 100 hrs continuous use (approx 600 tests per battery pack). Alternate replacement model LR44.
Dimensions	Unit only: 6.5"L x 1.5" dia (165 x 38 mm); Boxed: 7.25" x 2.75" x 1.87" (184 x 70 x 48 mm)
Weight	Unit only: 3.25 oz (90 g); Boxed: 6.0 oz (170 g)
Wetted materials	316 stainless steel (electrodes) and Valox® housing

\*For best accuracy, calibrate to 4.4 ppt NaCl with standard 00653-89 (order on page 40).

### Ordering Information

Catalog number	Description
WD-35661-51	Waterproof SaltTestr

### Accessories

**WD-35661-17** Replacement electrode for SaltTestr

**WD-35624-45** Vinyl carrying case with belt loop—holds one waterproof tester and solution pouches. Shpg wt 0.5 lb (227 g)

**WD-09377-16** Replacement batteries, 1.5 V, 6/pack  
**WD-35661-70** Deluxe Testr Calibration kit. Includes 2 each calibration pouches (447  $\mu$ S, 1413  $\mu$ S, 2764  $\mu$ S, 15,000  $\mu$ S, and rinse water), sample jar, foam-lined plastic carrying case. Order Testr separately. Shpg wt 0.7 lb (300 g)